



- Use a DMX repeater on each 32nd fixture of the daisy chain or in case the total DMX cable length exceeds 1000 ft (300m).
- Install a data terminator on the DMX OUT cable of the last unit of the daisy chain as described in the DMX connection kit manual.
- For further details on fixture connection and installation, please refer to the relevant instruction manual.

Description : ONYX CONFIGURATION SCHEME

Code :

Scale : 1:8

Weight :

Revision : A-01

SHEET 1 OF 1

Note :

