



- Use a DMX repeater on each 32nd fixture of the daisy chain or in case the total DMX cable length exceeds 1000 ft (300m).
- Install a data terminator on the DMX OUT cable of the last unit of the daisy chain as described in the DMX connection kit manual.
- For further details on fixture connection and installation, please refer to the relevant instruction manual.

Description : WATERLED MK2 CONFIGURATION SCHEME		
Code : .	Scale : .	Weight :
Revision : A-03	SHEET 1 OF 1	Note :

